

The Quick Guide is not intended as a substitute for your Owner's Manual. We strongly encourage you to review the Owner's Manual and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Air Conditioning System (without navigation system)*	
Using the automatic mode	74
Adjusting the temperature	74
Air Conditioning System (with navigation system)*	
Using the automatic mode	
Adjusting the temperature	66
Audio System (without navigation system) *	
Basic operation	71
Radio	71
CD player	72
Operating an iPod	
Remote control (steering wheel switches)	73
Audio System (with navigation system)*	
Audio control screen	62
Basic operation	62
Radio	63
DVD player/CD player	63
Operating an iPod	65
Remote control (steering wheel switches)	65
Automatic High Beam	38
Cruise Control	26
Door Locks	
Dynamic Radar Cruise Control	
Eco Driving Indicator Light	
Energy Monitor / Consumption Screen	
Fuel Tank Cap	
Garage Door Opener	81
Hands-free System For Cellular Phone (without navigation system) *	
Bluetooth $^{ ext{@}}$ phone pairing	67
Calling by number	67
Calling by name	68
Calling by speed dial	68
Phonebook transfer	69
Changing the registered name	70
Registering a speed dial	70
*: This feature may be operated by Voice Command (See P. 75)	

Hands-free System For Cellular Phone (with navigation system) *	
Bluetooth [®] phone pairing	54
Phonebook transfer	
Registering a voice tag	56
Registering a speed dial	
Calling by name	
Calling by speed dial	60
Receiving a call	61
Headlights	36
Head-up Display	
Hybrid System	
Hybrid transmission	
Intuitive Parking Assist	
Keys	
Lexus Enform with Safety Connect	
LKA (Lane-Keeping Assist)	
Moon Roof	
Multi-information Display	23
Navigation System*	
Register home	
Destination input - Search by address	
Destination input - Search points of interest by name	
Destination input - Search points of interest by category	
Destination input - Search points of interest by telephone number	
Voice Command System	
Portable Audio Device Adapters	80
Power (Ignition) Switch	
Power Windows	
Remote Touch	
Safety Connect	
Smart Access System with Push-button Start	
Theft Deterrent System	
Turn Signal Lever	25
Voice Command System*	
Basic operation	
Command list	
Wide View Front Monitor	
Windshield Wipers and Washer	39
*: This feature may be operated by Voice Command (See P. 75)	


Overview Instrument Panel FV drive mode switch P.22 "ECO MODE" switch P.21 "PWR MODE" switch P.21 Power (ignition) switch P.17 Windshield wiper and Multi-information washer switch P.39 display P.23 Headlight switch P.36 See P.6 Automatic high P.38 beam * Turn signal lever P.25 Fog light switch *1 See P.7 Door lock switches P.87 Driving position memory switches **1 Inside door lock buttons P.87 Window lock switch P.88 Power window switches P.88 Hood lock release lever Parking brake pedal *1 Tilt and telescopic steering control switch $*^{*1}$

Pre-collision braking off switch **1

Hybrid transmission shift lever P.19

P position switch P.20

Tilt and telescopic steering control lever **1





.

*2: Refer to "Navigation System Owner's Manual".

Overview


Instrument Panel





Overview

Instrument Panel



D Seat heater switches **1 Seat heater/ventilator switches **1 *: If equipped *1: Refer to "Owner's Manual". \star^2 : For vehicles with a navigation system, refer to

the "Navigation System Owner's Manual".

Overview

Roof

